

MMC SURFACE PREPARATION FOR SELF ADHESIVE WALL MURAL

Please follow the instructions as outlined below. Any variation may cause additional expenses.

NEW CONSTRUCTION

1. All drywall dust must be removed prior to painting the wall.
2. The wall must be painted with primer all the way to the perimeter edges.
3. Check the wall for any imperfections. Any imperfection will be magnified when the graphic is installed.
4. The wall must be painted with no less than a semi gloss finish.
5. The paint must dry/cure for a minimum of 72 hours. Oil base is two times the drying time on the can label.
6. The entire area of the wall that is to have graphics applied is to be painted.
7. Vinyl graphics will not adhere well to dry wall, drywall mud or primer, also paints that have a finish of flat or eggshell.
8. Any paint that states No VOC's has an extreme potential of failure when installing graphics.

EXISTING WALLS

1. Check the wall for any imperfections.
2. Wipe the area where the graphics is to be installed.
3. The wall must be painted with no less than a semi gloss finish.

Note:

The preparation of a wall is a vital part of the installation process. If the wall is not properly prepared the graphic will fail. Mega Media will not be responsible for graphics that fail due to surfaces that are not properly prepared as per instructions above.